Glenthorpe Engineering Est 1964	BODY FITTING SHAFT FITTIN

		SHAFT FITTING
"Type" (fitting configuration)	BODY	SHAFT
Type $1 = Male$ outlet on body/Loose nut nipple female outlet on shaft.	MALE	FEMALE (Loose Nut & Nipple)
Type $2 = Female fixed outlet on body/Female fixed outlet on shaft.$	FIXED FEMALE	FIXED FEMALE
Type 3 = "U" Configeration with Female fixed outlet on body/Female fixed outlet on shaft.	FIXED FEMALE	FIXED FEMALE
Type 4 = Loose nut female outlet on body/Male outlet on shaft.	FEMALE (Loose Nut & Nipple)	MALE
Type 5 = Loose nut female outlet on body/Loose nut female outlet on shaft.	FEMALE (Loose Nut & Nipple)	FEMALE (Loose Nut & Nipple)
Type 6 = Loose nut female outlet on body / Fixed female outlet on shaft.	FEMALE (Loose Nut & Nipple)	FIXED FEMALE
Type $7 = Male outlet on body/Male outlet on shaft.$	MALE	MALE
Type $8 = \text{Female fixed outlet on body/Male outlet on shaft.}$	FIXED FEMALE	MALE
Type 9 = Female fixed outlet on body/Loose nut female outlet on shaft	FIXED FEMALE	FEMALE (Loose Nut & Nipple)
Type 10 = Male outlet on body/Female fixed outlet on shaft	MALE	FIXED FEMALE
Inline is supplied as standard in the Type 8 configuration	FIXED FEMALE	MALE
"Type" (fitting configuration)	BODY	SHAFT